

Aerosol Line Striper Machine

Assembly Instructions

This Line Striper comes fully assembled except for the handle and the universal can holder.

- 1).** Remove the Striper Assembly from the box. Be careful not to over extend the control cable.
- 2).** Place the handle into the receiving hole at the top of the Striper body. (It may be necessary to rotate the handle 90 degrees to put into place). Once in place, align holes in handle to holes in handle mount. Open the hardware bag and identify the two $\frac{1}{4}$ " x $1\frac{1}{2}$ " bolts and the $\frac{1}{4}$ " split lock washers. Place the lock washers over each bolt. Carefully align the two holes in the handle with the holes in the Striper body and place the $\frac{1}{4}$ " bolts through the holes from the underside of the Striper body. Place one $\frac{1}{4}$ " flat washer over the end of the bolt that sticks through the Striper body and secure snugly with the wing nuts.
- 3).** Place the universal can holder in front of the universal can base and align the slot with the mounting hole. Place the wing bolt and washer through the can holder and secure lightly. This will allow the can holder to be adjusted accordingly with the size of can you are using. Make sure the forked end is facing toward the handle.
- 4).** Insert a can of paint and position the can holder directly over the bottom of the paint can. Gently apply pressure while tightening the wing bolt.

Line Width Adjustment

- 1).** Simply raise or lower the universal can base to adjust the line width. Loosen the two wing bolts located on each side of the Striper body, this will allow the universal can base to slide up and down accordingly. After adjusting to the desired height, tighten wing bolts securely and begin to paint.